

Disconnect power at electrical panel prior to installation and maintenance. Install in accordance with local regulations and National Electric Code by a person familiar with the construction and operation of the product and the hazards involved. Use only mating parts and accessories supplied by Spectrum Lighting.


INSTRUCTIONS FOR UNITS WITH DRIVER INSIDE BODY.

1. **DETERMINE LENGTH (L). Fig. 1**

- If needed cut CORD leaving enough to wire in J-BOX.
- Cut CORD LENGTH= (L + 7.5").
- Strip 6" of CORD JACKET. Strip each lead.

2. **ASSEMBLE CORD TO CROSSBAR. Fig. 2**

- Put CORD through CANOPY HOLE in orientation shown.
- Put CORD CLAMP in CROSSBAR in orientation shown. Note orientation with MAGNET.
- Clamp CORD JACKET straight in center of CORD CLAMP with 1" of CORD JACKET above CORD CLAMP. Tighten screws completely against CORD CLAMP.




3. **ASSEMBLE CROSSBAR TO J-BOX. Fig. 3**

- Orient MAGNETS away from J-BOX.
- Fasten CROSSBAR to J-BOX with two screws.

4. **CONNECT CORD WIRES TO PROPER SUPPLY VOLTAGE WIRES USING SUITABLE WIRE CONNECTORS (BY OTHERS). Fig. 3**

- Connect CROSSBAR GROUND WIRE and CORD green ground wire to supply ground wire.
- Connect white neutral supply to CORD white wire.
- Connect black hot supply to CORD black wire.



FOR 0-10V DIMMING.

- Connect CORD pink wire with control system pink or grey wire.
- CORD purple wire to control system purple wire.

ELV AND TRIAC DIMMING.

- Follow dimmer wiring diagram connect to CORD white and black leads.
- Cap CORD control wires pink and purple separately if they are not being used.
- Place all splices in J-BOX.

5. **SECURE CANOPY. Fig. 3.**

- Push CANOPY against CROSSBAR until CANOPY engages MAGNETS.

