

Disconnect power at electrical panel prior to installation and maintenance. Install in accordance with local regulations and National Electric Code by a person familiar with the construction and operation of the product and the hazards involved. Use only mating parts and accessories supplied by Spectrum Lighting.

INSTRUCTIONS FOR SURFACE REMOTE DRIVER.

EMERGENCY AND NON-EMERGENCY

CAUTION: Do Not Mount on Wall.

1. CONNECT DRIVER WIRES TO PROPER SUPPLY VOLTAGE

USING SUITABLE WIRE CONNECTORS (BY OTHERS). Fig.1

- Connect DRIVER green ground wire to MOUNTING BRACKET GROUND WIRE AND supply ground wire.
- Connect white neutral supply to white DRIVER wire.
- Connect black switched hot supply to black DRIVER wire.
- For EM version only. Connect orange DRIVER wire to UNSWITCHED hot supply wire.

FOR 0-10V DIMMING.

- Connect pink DRIVER wire with control system pink or grey wire. Purple DRIVER wire to purple control system wire.

ELV AND TRIAC DIMMING.

- Follow dimmer wiring diagram connect to DRIVER white and black leads.
- **Cap DRIVER control wires pink and purple separately if they are not being used.**

LUTRON DRIVER CONTROL WIRES (2) PURPLE

- Connect (1) purple DRIVER wire to (1) control system purple wire.
- Connect other DRIVER purple wire to other control system purple wire.

Place all splices in J-BOX.

2. MOUNT BACK PLATE TO J-BOX Fig.1

- Use KEY SLOTS on BACK PLATE to mount MOUNTING BRACKET to J-BOX SCREWS (by others).
- Tighten SCREWS to secure BACK PLATE.

3. FOR EM VERSION ONLY FIG. 2

- Run EM TEST SWITCH wire through CANOPY hole. Use NUT provided with EM TEST SWITCH to lock in place on CANOPY.
- Plug EM TEST SWITCH into PORT on BATTERY PACK.

4. INSTALL CANOPY TO BRACKET Fig.3,4

- Run red and blue DRIVER wires out center hole of CANOPY.
- Snap CANOPY onto SPRINGS.

5. CONNECT FIXTURE WIRES TO DRIVER LED WIRES. Fig.5

- Connect red DRIVER wire to red FIXTURE WIRE.
- Connect blue DRIVER wire to blue FIXTURE WIRE.

6. ATTACH BODY TO BRACKET FIG.6

- Push wires and splices safely into MOUNTING BRACKET though center CANOPY hole.
- Push BODY against CANOPY passing BALL through center of MOUNTING BRACKET SPRINGS taking care not to pinch wires.

TO REMOVE BODY AFTER INSTALLATION

Push BODY to side while pulling away from ceiling.




Fig.1




Fig.2




Fig.3

Fig.4




Fig.5




Fig.6